

altecnic

508 hydroscopic air vent



Application

The Altecnic hydroscopic automatic air vent can manually or automatically remove any air trapped within a radiator or heat emitter both during filling the system and in normal operation.

Construction Details

Component	Material	Grade		
Body	Brass - nickel plated	BS EN 121		

Body Brass - nickel plated BS EN 12164 CW614N Knob Polyacetal White RAL 9010

Connection seal PTFE


Technical Data

Max. Temperature: 90°C Max. Pressure: 10 bar

Operation


The Altecnic 508 air vent can be used manually or automatically.

By manually turning the operating knob, air in the radiator will start to escape, which should be allowed to continue until all the air is expelled when water starts to escape.




Close the air vent by turning the operating knob in the reverse direction.

In automatic mode the discharge of air is based on the properties of the cellulose fibre discs forming the sealing cartridge.




For manual operation unscrew the knob approximately one turn.

Typical use of this method is when filling or refilling the system.



The automatic discharge position is when the knob is in the fully closed position.


Dimensions



Product	Α	В	С	D		F
508011	G ¹ / ₈ B	30	18	10	20	15
508021	G¼B	30	18	10	20	15
508031	G³/8B	30.5	18	10.5	20	17
508041	G1∕2B	33	18	10	20	17

Hydroscopic Principle

The hydroscopic disc increases in volume by 50% when immersed in water.



The air vent cartridge contains a number of hydroscopic discs.

In this way, when the system is operating under normal conditions, the discs are immersed and due to their increase in volume, close the valve. However, when air is present the discs dry out and allow the air to vent.

Hydroscopic discs close very quickly, in just a few seconds.

The drying times are such that there are no problems with the cycle of formation and elimination of air.

Table of Drying Times


Water Temperature	40	50	60	70	80	90	100
Time in hours	6	5	21/2	11/2	1	1/2	1/4

Cartridge Replacement

The valve is designed in such a way that the part containing the hydroscopic discs can be easily replaced without having to empty the radiator.

This may be necessary if there is unfilted or hard water present.

It is advisable to replace the disc cartridge at least every 3 years.



E & O.E

Altecnic Ltd Mustang Drive, Stafford, Staffordshire ST16 1GW T: +44 (0)1785 218200 E: sales@altecnic.co.uk
Registered in England No: 2095101

